

Application instructions

P-01A Primer / Finishing Polish

Enhances the appearance of automotive paint and fills in light scratches. Can be used for the improvement of rough paint surface, swirls, marring, holograms and other imperfections. Only suitable for usage in combination with other products of the Modesta products line.

- 1. Prepare the surface by polishing** Do not use compounds with masking abilities as these may negatively influence the bonding of the coating. If left on the paint they must be removed in step 2. The finish of the paint should always be perfect with no swirls and holograms left.
- 2. Thoroughly clean the surface** Use a good quality paint cleaner or wash the vehicle using active foam or citrus cleaner. You may consider using a "poly cracker" or silicone remover in this step. Products that leave a residue on the paint surface are not suitable (for example products with an anti static effect).
- 3. Mask all rubber and plastic parts** The product might negatively affect the appearance of rubber and unpainted plastic parts if it comes in contact with them. Clearcoated poly carbonate parts (for example headlights) will not be affected and can be treated with this product.
- 4. Thoroughly degrease the surface** It is recommended to use alcohol without any additives (pure isopropyl alcohol in 99% concentration). This step is important as the product might not work as expected unless the surface is completely degreased. Panel wipe or silicone remover is not a replacement.
- 5. Spread product on panel** Work on one panel only. Apply a small amount of the product to a clean buffing pad or applicator. Machine and hand application may be used. If working by hand work in with circular motions and overlap passes.
- 6. Wait for 2-3 minutes** This time is calculated at 22 degrees Celsius. The curing might be faster with higher temperatures. Do not leave to dry fully on paint.
- 7. Wipe with a clean microfiber** Wipe with a clean dry microfiber until smooth and shiny. Pay great attention to remove all excess in the wipe.
- 8. Leave to rest for at least 180 minutes** Do not apply a coating on top of the P-01A Primer within a minimum 3 hours period after wiping off the excess in step 7. Infrared curing is not suitable to fasten this process.
- 9. Continue with application** Application of coatings may be started 3 hours after wiping off the excess. Additional layer thickness may be achieved by a combination of machine and hand application and repeating steps 5-8.